

HINSHI-H10-001-2

SERVICE MANUAL

MARINE DIESEL ENGINE

6LP-DTE/-DTZE(1)

6LPA-DTP/-DTZP

6LP-STE/-STZE(1)

6LPA-STP/-STZP

2001.6

YANMAR

SERVICE MANUAL

MARINE DIESEL ENGINE

MODEL **6LP-DTE/-DTZE(1)**
6LPA-DTP/-DTZP
6LP-STE/-STZE(1)
6LPA-STP/-STZP



YANMAR DIESEL ENGINE CO., LTD.

History of Revision					Page No.	1
Manual Name		Yanmar Service Manual for Marine Diesel Engine				
Engine Model:		6LP-DTE/DTZE/DTZE1, 6LPA-DTP/DTZP, 6LP-STE/STZE/STZE1, 6LPA-STP/STZP				
Number of revision	Date of revision	Reason for correction	Outline of correction	Correction item No.(page)	Corrected by	
<ul style="list-style-type: none"> ● New edition July 1998 ● 1st revised edition April 1999 (Publication No. HINSHI-H10-001-1) 6LP-DTZE1, 6LP-STZE1 (less power steering oil pump) added ● 2nd revised edition Jun., 2001 (Publication No. HINSHI-H10-001-2) 6LPA-DTP/DTZP/STP/STZP added. Revised pages: -ii-, -iii-, -iv-, -v-, -vi-, -vii-, -viii-, -ix-, -x-, -xi-, -xii-, -xiii-, -xiv-, -xv-, -xvi-, -xvii-, 2-1, 2-2, 2-3, 2-4, 2-5, 2-10, 2-11, 3-1, 3-75, 3-132, 5-1, 5-2, 5-3(E), 6-1, 6-2, 6-3(E), 7-3, coverpages and back pages Added pages: 2-1-2, 2-1-3, 2-7-2, 2-7-3, 2-7-4 and 2-7-5 						

FOREWORD

This manual describes the service procedures for the 6LP and 6LPA series marine diesel engine.

Please use this manual for accurate, quick and safe servicing of the respective engine. Since the explanation herein assumes the standard type engine, the specifications and components may partially be different from the engine installed on each boat. Please also refer to the service manual for each boat for details.

The specifications and components are subject to change for improvement of the engine quality. If any modification of the contents described in this manual becomes necessary, it will be notified in the form of a correction notice each time.

California

Proposition 65 Warning

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

California

Proposition 65 Warning

Battery posts, terminals, and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm.

The contents of this service manual may not be copied or reproduced without permission.

CONTENTS

Notice: The descriptions for the 6LP-DTE series also apply to 6LPA-DTP series. The descriptions for the 6LP-STE series also apply to 6LPA-STP series.

1. For Safe Operation	1-1
1.1 Warning Symbols	1-1
1.2 Precautions for Safe Servicing	1-2
1.3 Location for Product Safety Labels	1-6
2. General	2-1
2.1 Specifications	2-1
2.2 External Views	2-2
2.3 Piping Diagram	2-4
2.4 Performance Curves	2-6
2.5 Front Power Take-Off (PTO) Output	2-8
2.6 Fuel Oil	2-10
2.7 Lube Oil	2-11
2.8 Cooling Water	2-11
2.9 Location of Senders and Warning Switches	2-12
3. Engine Overhaul	3-1
3.1 Cylinder Head	3-1
3.1.1 Components	3-1
3.1.2 Removal of Cylinder Head	3-4
3.1.2.1 Drain the engine cooling water.	3-4
3.1.2.2 Remove the turbocharger	3-4
3.1.2.3 Remove the fresh water tank.....	3-4
3.1.2.4 Remove the fuel filter.....	3-4
3.1.2.5 Remove the intake manifold and intercooler.....	3-4
3.1.2.6 Remove the fuel injection pipe and fuel injection nozzle (For 6LP-DTE series).	3-4
3.1.2.7 Remove the bonnet.	3-5
3.1.2.8 Remove the semi-circular plug	3-5
3.1.2.9 Remove the timing belt and pulley	3-5
3.1.2.10 Remove the camshaft oil seal retainer.....	3-5
3.1.2.11 Remove the fuel injection nozzle (6LP-STE series)	3-5

3.1.2.12	Remove the camshaft (6LP-STE series)	3-5
3.1.2.13	Remove the cylinder head assy.....	3-5
3.1.3	Disassembly of Cylinder Head	3-7
3.1.3.1	Remove the valve lifter and shim (6LP-DTE series only)	3-7
3.1.3.2	Remove the valve bridge (6LP-STE series only)	3-7
3.1.3.3	Remove the intake and exhaust valves	3-7
3.1.4	Inspection and Servicing of Cylinder Head Components	3-7
3.1.4.1	Clean the piston and cylinder block top surfaces	3-7
3.1.4.2	Clean the cylinder head	3-8
3.1.4.3	Inspect the cylinder head.....	3-9
3.1.4.4	Clean the intake and exhaust valves	3-9
3.1.4.5	Inspection of valve stem and valve guide	3-9
3.1.4.6	Inspect and lap the intake and exhaust valves.....	3-10
3.1.4.7	Inspect and clean the valve seat.....	3-11
3.1.4.8	Check the valve spring	3-12
3.1.4.9	Check the valve rocker arm and shaft (For 6LP-STE series only)	3-13
3.1.4.10	Check the camshaft and bearing	3-14
3.1.5	Replacement of Oil Seal for Camshaft.....	3-16
3.1.6	Assembly of Cylinder Head	3-17
3.1.6.1	Install the intake and exhaust valves	3-17
3.1.6.2	Install the valve bridge (6LP-STE series)	3-18
3.1.6.3	Install the valve lifter and shim (6LP-DTE series only)	3-18
3.1.7	Installation of Cylinder Head	3-19
3.1.7.1	Measure protrusion of piston head for top surface of cylinder block to determine an appropriate cylinder head gasket	3-19
3.1.7.2	Set cylinder No.1 at the bottom dead center	3-20
3.1.7.3	Install the cylinder head	3-21
3.1.7.4	Install the camshaft	3-22
3.1.7.5	Install the fuel injection nozzle	3-23
3.1.7.6	Install the camshaft oil seal retainer.....	3-23
3.1.7.7	Install the pulley and timing belt.....	3-24
3.1.7.8	Check and adjust the valve clearance	3-24
3.1.7.9	Install the semi-circular plug	3-24
3.1.7.10	Install the bonnet	3-24
3.2	Cylinder Block	3-25
3.2.1	Components	3-25
3.2.2	Preparation for Disassembly	3-26

3.2.2.1	Remove the flywheel	3-26
3.2.2.2	Install the engine on the engine stand for disassembling it.....	3-26
3.2.2.3	Remove the timing belt and pulley.....	3-26
3.2.2.4	Remove the cylinder head	3-26
3.2.2.5	Remove the fresh water pump and sea water pump.....	3-26
3.2.2.6	Remove the alternator	3-26
3.2.2.7	Remove the timing gear	3-26
3.2.2.8	Remove the fuel injection pump	3-26
3.2.2.9	Remove the oil pan and timing gear case.....	3-26
3.2.2.10	Remove the oil cooler.....	3-26
3.2.2.11	Remove the engine mount.....	3-26
3.2.3	Disassembly of Cylinder Block	3-27
3.2.3.1	Remove the rear oil seal case	3-27
3.2.3.2	Check the connecting rod thrust clearance.....	3-27
3.2.3.3	Remove the connecting rod cap and check oil clearance	3-27
3.2.3.4	Remove the piston and connecting rod assembly.....	3-29
3.2.3.5	Inspect the thrust clearance of the crankshaft	3-29
3.2.3.6	Remove the main bearing cap and inspect the oil clearance	3-29
3.2.3.7	Remove the crankshaft.....	3-32
3.2.3.8	Remove the check valve and oil nozzle (for piston cooling)	3-32
3.2.4	Inspection of Cylinder Block	3-32
3.2.4.1	Clean the cylinder block.....	3-32
3.2.4.2	Measure warpage of the top surface of cylinder block	3-32
3.2.4.3	Visually check scratches of the cylinder in the vertical direction	3-32
3.2.4.4	Measure the cylinder bore diameter	3-32
3.2.4.5	Clean the cylinder ridge	3-33
3.2.4.6	Inspect the main bearing cap bolt.....	3-33
3.2.5	Disassembly of Piston and Connecting Rod.....	3-34
3.2.5.1	Check fitting between the piston and piston pin.....	3-34
3.2.5.2	Remove the piston ring.....	3-34
3.2.5.3	Remove the connecting rod from the piston	3-34
3.2.6	Inspection of Piston and Connecting Rod	3-35
3.2.6.1	Clean the piston.....	3-35
3.2.6.2	Inspect the piston and piston ring	3-35
3.2.6.3	Inspect the piston pin fit.....	3-37
3.2.6.4	Inspect the connecting rod	3-37
3.2.7	Inspection and Servicing of Crankshaft	3-39
3.2.7.1	Measure circle runout of the crankshaft.....	3-39
3.2.7.2	Inspect the crank journal and crank pin	3-39
3.2.8	Replacement of Oil Seal for Crankshaft	3-40
3.2.8.1	When the rear oil seal case has been removed from the cylinder block.....	3-40
3.2.8.2	When the rear oil seal case is installed to the cylinder block	3-40

3.2.9	Assembly of Piston and Connecting Rod	3-40
3.2.9.1	Assemble the piston and connecting rod	3-40
3.2.9.2	Install the piston ring.....	3-41
3.2.9.3	Install the crank pin bearing.....	3-42
3.2.10	Assembly of Cylinder Block	3-42
3.2.10.1	Install the oil nozzle and check valve for the piston cooling	3-42
3.2.10.2	Install the main bearing	3-42
3.2.10.3	Place the crankshaft on the cylinder block.....	3-43
3.2.10.4	Install the thrust bearing	3-43
3.2.10.5	Install the main bearing cap.....	3-43
3.2.10.6	Inspect the thrust clearance of the crankshaft	3-44
3.2.10.7	Install the piston and connecting rod assembly	3-44
3.2.10.8	Install the connecting rod cap	3-45
3.2.10.9	Check the connecting rod thrust clearance.....	3-45
3.2.10.10	Install the rear oil seal case	3-46
3.2.11	Next Assembly	3-47
3.2.11.1	Install the engine mounting bracket	3-47
3.2.11.2	Install the timing gear case	3-47
3.2.11.3	Install the oil pan.....	3-47
3.2.11.4	Install the rear end plate	3-47
3.2.11.5	Install the flywheel	3-47
3.2.11.6	Install the flywheel housing by tightening the set bolts.....	3-47
3.2.11.7	Upside down the engine and place it on the engine stand	3-47
3.2.11.8	Install the thermostat	3-47
3.2.11.9	Install the alternator and bracket assembly.....	3-47
3.2.11.10	Install the fresh water pump.....	3-47
3.2.11.11	Install the cylinder head	3-47
3.2.11.12	Install the timing belt and pulley.....	3-47
3.2.11.13	Remove the engine from the engine stand	3-47
3.2.11.14	Install the turbocharger oil pipe.....	3-47
3.2.11.15	Install the oil cooler assembly, oil dipstick and guide	3-47
3.2.11.16	Install the sender units and warning switches	3-47
3.2.11.17	Install the fuel injection pump	3-47
3.2.11.18	Install the sea water pump.....	3-47
3.2.11.19	Install the lube oil filter	3-47
3.3	Timing Belt	3-48
3.3.1	Components	3-48
3.3.2	Removal of Timing Belt	3-49
3.3.2.1	Remove the timing belt cover	3-49
3.3.2.2	Set the No.1 cylinder at the bottom dead center (BDC)	3-49
3.3.2.3	Remove the timing belt.....	3-49
3.3.2.4	Remove the idler pulley	3-50
3.3.2.5	Remove No.2 camshaft timing pulley	3-50
3.3.2.6	Remove the bonnet	3-50

3.3.2.7	Remove No.1 camshaft timing pulley	3-50
3.3.3	Checking of Timing Belt	3-50
3.3.3.1	Checking the timing belt	3-50
3.3.3.2	Inspect the idler pulley	3-52
3.3.3.3	Inspect the tension spring and tensioner	3-52
3.3.4	Installation of Timing Belt	3-53
3.3.4.1	Install No.1 camshaft timing pulley	3-53
3.3.4.2	Install the bonnet	3-53
3.3.4.3	Install No.2 camshaft timing pulley	3-53
3.3.4.4	Install the idler pulley	3-54
3.3.4.5	Set the No.1 cylinder to the bottom dead center (BDC)	3-54
3.3.4.6	Install the timing belt.....	3-54
3.3.4.7	Install the tension spring (6LP-DTE series).....	3-55
3.3.4.8	Install the timing belt tensioner (6LP-STE series)	3-55
3.3.4.9	Inspect the valve timing	3-55
3.3.4.10	Install the timing belt cover	3-56
3.4	Timing Gear	3-57
3.4.1	Components	3-57
3.4.2	Removal of Timing Gear	3-58
3.4.2.1	Remove the V-belt for driving the fresh water pump and alternator	3-58
3.4.2.2	Loosen the crankshaft pulley	3-58
3.4.2.3	Remove the timing belt and pulley.....	3-58
3.4.2.4	Remove the camshaft oil seal retainer.....	3-58
3.4.2.5	Remove the crankshaft pulley	3-58
3.4.2.6	Remove the alternator adjusting bar.....	3-58
3.4.2.7	Remove the timing gear cover	3-58
3.4.2.8	Remove the oil pump drive shaft gear	3-58
3.4.2.9	Inspect thrust clearance of the idler gear.....	3-59
3.4.2.10	Remove the idler gear	3-59
3.4.2.11	Remove the fuel injection pump drive gear.....	3-59
3.4.2.12	Remove the crankshaft timing gear	3-59
3.4.3	Inspection of Timing Gear	3-60
3.4.2.1	Check the idler gear	3-60
3.4.3.2	Check the fuel injection pump drive gear bearing	3-60
3.4.3.3	Replace the fuel injection pump drive gear bearing, as needed.....	3-60
3.4.3.4	Inspect backlash of the timing gear	3-61
3.4.4	Replacement of Crankshaft Front Oil Seal	3-61
3.4.4.1	Replace the crankshaft front oil seal.....	3-61
3.4.5	Replacement of Fuel Injection Pump Drive Gear Oil Seal	3-62
3.4.5.1	Replace the fuel injection pump drive gear oil seal	3-62
3.4.6	Installation of Timing Gear	3-63
3.4.6.1	Install the crankshaft timing gear	3-63
3.4.6.2	Install the fuel injection pump drive gear.....	3-63

3.4.6.3	Install the idler gear	3-63
3.4.6.4	Install the oil pump drive shaft gear	3-64
3.4.6.5	Install the timing gear cover.....	3-64
3.4.6.6	Install the alternator adjusting bar.....	3-64
3.4.6.7	Install the crankshaft pulley	3-65
3.4.6.8	Install camshaft oil seal retainer	3-65
3.4.6.9	Install timing pulleys and timing belt	3-65
3.4.6.10	Tighten crankshaft pulley bolt	3-65
3.4.6.11	Install the V-belt for driving the fresh water pump and alternator	3-65
3.5	Valve Clearance Inspection and Adjustment	3-66
3.5.1	Inspection of Valve Clearance.....	3-66
3.5.1.1	Remove the bonnet	3-66
3.5.1.2	Set No.1 cylinder to the top dead center (TDC)	3-66
3.5.1.3	Inspect the valve clearance	3-66
3.5.2	Adjustment of Valve Clearance	3-67
3.5.2.1	Adjust the valve clearance.....	3-67
3.5.2.2	Install the bonnet.....	3-68
3.6	Inspection and Adjustment of Injection Timing	3-69
3.6.1	Inspection of Injection Timing.....	3-69
3.6.1.1	Set the No.1 or No.6 cylinder at the top dead center (TDC) /compression	3-69
3.6.1.2	Install the plunger stroke measuring tool and dial indicator	3-69
3.6.1.3	Inspect the injection timing	3-69
3.6.2	Adjustment of Injection Timing	3-70
3.6.2.1	Adjust the injection timing.....	3-70
3.6.2.2	Tighten union nuts for the fuel injection pipe	3-70
3.6.2.3	Start the engine and check for fuel oil leakage.....	3-70
3.7	Service Specifications	3-71
3.7.1	Engine Adjusting Standards.....	3-71
3.7.2	Service Standards	3-72
3.7.3	Nut and Bolt Tightening Torque.....	3-75
3.8	Turbocharger.....	3-76
3.8.1	Construction and Function.....	3-76
3.8.1.1	Overview of construction and function	3-76
3.8.1.1.1	Turbine	3-76
3.8.1.1.2	Blower.....	3-76
3.8.1.1.3	Bearing	3-76
3.8.1.1.4	Sealing structure at blower side	3-76
3.8.2	Components (RHE6W Turbocharger)	3-78
3.8.3	Service Specifications	3-79
3.8.3.1	Service standards.....	3-79

3.8.3.2	Nut and bolt tightening torque.....	3-80
3.8.4	Periodic Inspection Procedure.....	3-81
3.8.4.1	Periodic inspection intervals	3-81
3.8.4.2	Inspection procedure	3-81
3.8.4.2.1	Running of turbine shaft.....	3-81
3.8.4.2.2	Inspection of turbine shaft play	3-82
3.8.5	Disassembly Procedure.....	3-83
3.8.5.1	Preparation for disassembly	3-83
3.8.5.2	Inspection before disassembly	3-84
3.8.5.2.1	Check the turbine and compressor impellers for interference. Also, check that the turbine shaft rotates smoothly.....	3-84
3.8.5.2.2	Measure the turbine shaft play.....	3-84
3.8.5.3	Disassembly	3-84
3.8.5.3.1	Remove the boost hose	3-84
3.8.5.3.2	Remove the compressor housing	3-84
3.8.5.3.3	Remove the compressor impeller	3-84
3.8.5.3.4	Remove the seal plate	3-85
3.8.5.3.5	Remove the turbine housing	3-85
3.8.5.3.6	Pull off the turbine shaft.....	3-85
3.8.5.3.7	Remove the thrust bearing and thrust bushing	3-85
3.8.5.3.8	Remove the floating bearing	3-85
3.8.5.3.9	Remove the seal ring.....	3-85
3.8.6	Cleaning and Checking Procedures	3-86
3.8.6.1	Cleaning	3-86
3.8.6.1.1	Checking before cleaning	3-86
3.8.6.1.2	Cleaning procedure	3-87
3.8.6.2	Inspection procedure	3-88
3.8.6.2.1	Compressor housing ③.....	3-88
3.8.6.2.2	Turbine housing ④.....	3-88
3.8.6.2.3	Compressor impeller ⑧	3-88
3.8.6.2.4	Turbine shaft ①	3-88
3.8.6.2.5	Thermal insulation plate ④.....	3-88
3.8.6.2.6	Thrust bushing ②, oil thrower ③ and thrust bearing ②.....	3-89
3.8.6.2.7	Floating bearing ②.....	3-89
3.8.6.2.8	Bearing housing ⑤.....	3-90
3.8.6.2.9	Seal plate ⑪	3-90
3.8.6.2.10	Seal rings ④ and ⑥	3-90
3.8.6.2.11	Check bolts, etc. for deformation	3-90
3.8.7	Reassembly Procedure.....	3-91
3.8.7.1	Preparation for reassembly.....	3-91
3.8.7.1.1	Prepare tools	3-91
3.8.7.1.2	Replace the parts.....	3-91
3.8.7.2	Reassembly.....	3-91
3.8.7.2.1	Installation of floating bearing	3-91
3.8.7.2.2	Installation of turbine shaft.....	3-91

3.8.7.2.3	Installation of thrust bearing	3-91
3.8.7.2.4	Installation of turbine housing	3-92
3.8.7.2.5	Installation of seal plate	3-92
3.8.7.2.6	Installation of compressor impeller.....	3-92
3.8.7.2.7	Installation of compressor housing.....	3-93
3.8.7.2.8	Installation of boost hose	3-93
3.8.7.2.9	Measurement of turbine shaft play.....	3-93
3.8.8	Handling after Disassembly and Reassembly.....	3-94
3.8.8.1	Instructions for turbocharger installation	3-94
3.8.8.1.1	Lubrication path	3-94
3.8.8.1.2	Intake path.....	3-94
3.8.8.1.3	Exhaust path.....	3-94
3.8.9	Troubleshooting.....	3-95
3.8.9.1	Excessively dense exhaust smoke	3-95
3.8.9.2	White exhaust gas color	3-96
3.8.9.3	Excessive engine oil consumption	3-96
3.8.9.4	Engine output drop	3-96
3.8.9.5	Poor (slow) response (starting) of turbocharger.....	3-96
3.8.9.6	Abnormal sound or vibration	3-97
3.9	Fuel Filter Replacement.....	3-98
3.9.1	Removal of Fuel Filter.....	3-98
3.9.1.1	Disconnect the connector of the water alarm switch of the fuel filter.....	3-98
3.9.1.2	Drain fuel from the fuel filter	3-98
3.9.1.3	Fuel filter removal.....	3-98
3.9.1.4	Remove the water alarm switch from the fuel filter	3-98
3.9.2	Installation of Fuel Filter.....	3-98
3.9.2.1	Install the water alarm switch to the new fuel filter	3-98
3.9.2.2	Install the new fuel filter	3-98
3.9.2.3	Install the water alarm switch connector of the fuel filter.....	3-98
3.9.2.4	Fill fuel to the fuel filter.....	3-98
3.9.2.5	Start the engine to check for fuel leakage	3-98
3.10	Fuel Injection Nozzle.....	3-99
3.10.1	Components	3-99
3.10.2	Removal of Fuel Injection Nozzle.....	3-100
3.10.3	Testing the Fuel Injection Nozzle.....	3-102
3.10.3.1	Leak test.....	3-102
3.10.3.2	Testing the spray condition.....	3-102
3.10.4	Components of Fuel Injection Nozzle.....	3-103
3.10.5	Disassembly of Fuel Injection Nozzle	3-104
3.10.5.1	Disassemble the fuel injection nozzle	3-104
3.10.6	Cleaning and Inspection of Fuel Injection Nozzle.....	3-104
3.10.6.1	Cleaning the nozzle	3-104

3.10.6.2	Inspection of nozzle assembly	3-105
3.10.7	Adjustment of Fuel Injection Nozzle	3-105
3.10.7.1	Adjust the needle lift and pre-lift	3-105
3.10.7.2	For 6LP-DTE series	3-105
3.10.7.3	For 6LP-STE series	3-108
3.10.8	Checking No.2 Opening Pressure	3-112
3.10.9	Adjusting No.1 Opening Pressure	3-114
3.10.10	Installation of Fuel Injection Nozzle	3-116
3.10.10.1	Install the fuel injection nozzle	3-116
3.10.10.2	Install the nozzle holder seal	3-116
3.10.10.3	Install the fuel injection pipe	3-116
3.10.10.4	Install the fuel return pipe	3-117
3.10.10.5	Install the bonnet	3-117
3.10.10.6	Start the engine and check for fuel leakage	3-117
3.11	Fuel Injection Pump	3-118
3.11.1	Removal of Fuel Injection Pump	3-119
3.11.1.1	Drain cooling water from the engine and disconnect the cooling pipe	3-119
3.11.1.2	Remove the timing belt	3-119
3.11.1.3	Remove the No.2 camshaft timing pulley	3-119
3.11.1.4	Remove the fuel injection pipe	3-119
3.11.1.5	Disconnect the boost compensator hose	3-119
3.11.1.6	Remove the fuel injection pump	3-119
3.11.2	Components	3-121
3.11.3	Installation of Fuel Injection Pump	3-123
3.11.3.1	Install the fuel injection pump	3-123
3.11.3.2	Connect boost compensator hose	3-124
3.11.3.3	Install the No.2 camshaft timing pulley	3-124
3.11.3.4	Install the timing belt	3-124
3.11.3.5	Check the injection timing	3-124
3.11.3.6	Install the fuel injection pipe	3-124
3.11.3.7	Fill with engine coolant (fresh water line)	3-124
3.11.3.8	Start the engine and check for fuel leakage	3-124
3.12	Fuel System Service Specifications	3-125
3.12.1	Service Standards	3-125
3.12.2	Nut and Bolt Tightening Torque	3-126
3.12.3	Specifications of Fuel Injection Pump	3-127
3.13	Fresh Water Pump	3-129
3.13.1	Removal of Fresh Water Pump	3-129
3.13.1.1	Drain engine cooling water	3-129
3.13.1.2	Remove the drive belt, viscous damper and fresh water pump pulley	3-129

3.13.1.3	Remove the timing belt.....	3-129
3.13.1.4	Remove the idler pulley	3-129
3.13.1.5	Remove No.1 camshaft timing pulley	3-130
3.13.1.6	Remove the camshaft oil seal retainer.....	3-130
3.13.1.7	Remove the fresh water pump.....	3-130
3.13.2	Inspection of Fresh Water Pump	3-130
3.13.2.1	Check the fresh water pump.....	3-130
3.13.3	Installation of Fresh Water Pump	3-130
3.13.3.1	Install the fresh water pump.....	3-130
3.13.3.2	Install the camshaft oil seal retainer.....	3-130
3.13.3.3	Install No.1 camshaft timing pulley	3-130
3.13.3.4	Install the idler pulley	3-131
3.13.3.5	Install the timing belt.....	3-131
3.13.3.6	Install the fresh water pump pulley, drive belt and viscous damper	3-131
3.13.3.7	Fill with engine coolant (fresh water)	3-131
3.13.3.8	Start the engine and check for water leakage.....	3-131
3.14	Sea Water Pump.....	3-132
3.14.1	Disassembly of Sea Water Pump.....	3-132
3.14.2	Inspection of Sea Water Pump.....	3-132
3.14.3	Reassembly of Sea Water Pump	3-132
3.15	Thermostat	3-133
3.15.1	Removal of Thermostat.....	3-133
3.15.2	Inspection of Thermostat.....	3-134
3.15.3	Installation of Thermostat	3-134
3.15.3.1	Install the thermostat on the cylinder block	3-134
3.15.3.2	Install the thermostat cover.....	3-134
3.15.3.3	Fill with engine coolant (fresh water)	3-134
3.15.3.4	Start the engine and check for water leakage.....	3-134
3.16	Components Related to Cooling System	3-135
3.16.1	Fresh Water Tank	3-135
3.16.1.1	Remove the pressure cap.....	3-135
3.16.1.2	Check the pressure cap.....	3-135
3.16.1.3	Check for fresh water leakage	3-135
3.16.1.4	Reinstall the pressure cap	3-135
3.16.2	Fresh Water Cooler	3-136
3.16.3	Subtank.....	3-136
3.16.3.1	Install the subtank	3-136
3.16.3.2	Subtank operational precautions	3-137
3.16.4	Kingston Cock (Optional)	3-137

3.17	Lubrication	3-138
3.17.1	Inspection of Oil Pressure	3-138
3.17.1.1	Check the lube oil quality	3-138
3.17.1.2	Check the lube oil level	3-138
3.17.1.3	Remove the oil pressure sender unit	3-138
3.17.1.4	Attach the oil pressure gauge	3-138
3.17.1.5	Warm up the engine	3-138
3.17.1.6	Check the oil pressure	3-138
3.17.1.7	Remove the oil pressure gauge	3-138
3.17.1.8	Install the oil pressure sender unit	3-138
3.17.1.9	Start the engine and check for oil leakage	3-138
3.17.2	Replacement of Lube Oil and Oil Filter	3-139
3.17.2.1	Drain the lube oil	3-139
3.17.2.2	Replace the lube oil filter	3-139
3.17.2.3	Fill with lube oil	3-139
3.17.2.4	Start the engine and check for oil leakage	3-139
3.17.2.5	Check the lube oil level again and replenish as needed	3-139
3.18	Oil Pump	3-140
3.18.1	Removal of Oil Pump	3-141
3.18.1.1	Drain the engine cooling fresh water	3-141
3.18.1.2	Drain the lube oil	3-141
3.18.1.3	Remove the timing gear	3-141
3.18.1.4	Remove the oil pan	3-141
3.18.1.5	Remove the oil pump (timing gear case)	3-141
3.18.1.6	Remove the oil strainer	3-141
3.18.2	Disassembly of Oil Pump	3-142
3.18.2.1	Remove the driven rotor	3-142
3.18.2.2	Remove the relief valve	3-142
3.18.3	Inspection of Oil Pump	3-142
3.18.3.1	Check the relief valve	3-142
3.18.3.2	Check the drive shaft	3-142
3.18.3.3	Check the drive and driven rotors	3-142
3.18.4	Reassembly of Oil Pump	3-143
3.18.4.1	Install the relief valve	3-143
3.18.4.2	Install the drive and driven rotors	3-143
3.18.5	Installation of Oil Pump	3-143
3.18.5.1	Install the oil strainer	3-143
3.18.5.2	Install the oil pump (timing gear case)	3-143
3.18.5.3	Pour lube oil into the oil pump	3-144
3.18.5.4	Install the oil pan	3-145
3.18.5.5	Install the timing gear	3-145
3.18.5.6	Fill with lube oil	3-145
3.18.5.7	Fill with engine coolant (fresh water)	3-145

3.18.5.8	Start the engine and check for oil leakage.....	3-145
3.18.5.9	Check the lube oil level again and, if needed, replenish up to the upper limit of the oil dipstick	3-145
3.19	Oil Cooler (Cooling by Fresh Water).....	3-146
3.19.1	Removal of Oil Cooler.....	3-147
3.19.1.1	Drain the engine coolant (fresh water).....	3-147
3.19.1.2	Remove the timing belt.....	3-147
3.19.1.3	Remove No.2 camshaft timing pulley	3-147
3.19.1.4	Remove the fuel injection pipe.....	3-147
3.19.1.5	Remove the fuel injection pump	3-147
3.19.1.6	Remove the oil filter.....	3-147
3.19.1.7	Remove the relief valve	3-147
3.19.1.8	Remove the check valve.....	3-147
3.19.1.9	Remove the oil cooler and cover assembly.....	3-147
3.19.1.10	Remove the oil cooler from the oil cooler cover	3-147
3.19.2	Inspection of Oil Cooler and Relief Valve.....	3-147
3.19.2.1	Check the relief valve	3-147
3.19.2.2	Check the check valve.....	3-148
3.19.2.3	Check the oil cooler	3-148
3.19.3	Installation of Oil Cooler.....	3-148
3.19.3.1	Install the oil cooler to the oil cooler cover	3-148
3.19.3.2	Install the oil cooler and cover assembly	3-148
3.19.3.3	Install the relief valve	3-149
3.19.3.4	Install the check valve	3-149
3.19.3.5	Install the oil filter.....	3-149
3.19.3.6	Install the fuel injection pump	3-149
3.19.3.7	Install the fuel injection pipe.....	3-149
3.19.3.8	Install No.2 camshaft timing pulley	3-149
3.19.3.9	Install the timing belt.....	3-149
3.19.3.10	Fill with engine coolant (fresh water)	3-149
3.19.3.11	Start the engine and check for oil leakage.....	3-149
3.19.3.12	Check the lube oil level again and, if needed, replenish up to the upper limit of the oil dipstick	3-149
3.20	Piston Cooling Oil Nozzle.....	3-150
3.20.1	Disassembly of Oil Nozzle.....	3-150
3.20.1.1	Remove the oil pan.....	3-150
3.20.1.2	Remove the check valve and oil nozzle	3-150
3.20.2	Inspection of Oil Nozzle.....	3-150
3.20.2.1	Check the check valve.....	3-150
3.20.2.2	Inspect the oil nozzle	3-151
3.20.3	Installation of Oil Nozzle.....	3-151
3.20.3.1	Install the oil nozzle and check valve	3-151
3.20.3.2	Install the oil pan.....	3-151

3.21	Service Specifications	3-151
3.21.1	Service Standards	3-151
3.21.2	Nut and bolt tightening torque	3-151
3.22	Starter	3-152
3.22.1	Components	3-152
3.22.2	Disassembly of Starter	3-152
3.22.2.1	Remove the field frame and lead wire with armature from the magnetic switch	3-152
3.22.2.2	Remove the starter housing, clutch assembly and gear	3-153
3.22.2.3	Remove the steel ball	3-153
3.22.2.4	Remove the brush holder	3-154
3.22.2.5	Remove the armature from the field frame	3-154
3.22.3	Inspection and Repair of Starter	3-154
3.22.3.1	Armature coil	3-154
3.22.3.1.1	Check the commutator for open circuit	3-154
3.22.3.1.2	Check grounding of the commutator	3-154
3.22.3.2	Commutator.....	3-154
3.22.3.2.1	Check the commutator surface for dirt and burning	3-154
3.22.3.2.2	Check the commutator for circle runout	3-154
3.22.3.2.3	Check the commutator diameter	3-155
3.22.3.2.4	Check the undercut depth.....	3-155
3.22.3.3	Field frame (Field coil)	3-155
3.22.3.3.1	Check open circuit of the field coil.....	3-155
3.22.3.3.2	Check grounding of the field coil.....	3-155
3.22.3.4	Brush.....	3-156
3.22.3.4.1	Check the brush length.....	3-156
3.22.3.5	Brush spring	3-156
3.22.3.5.1	Check the brush spring load	3-156
3.22.3.6	Brush holder	3-156
3.22.3.6.1	Check the insulation status of the brush holder	3-156
3.22.3.7	Clutch and gear	3-156
3.22.3.7.1	Check the gear tooth surfaces	3-156
3.22.3.7.2	Check the clutch pinion gear.....	3-157
3.22.3.7.3	Replace the clutch assembly if needed.....	3-157
3.22.3.8	Bearing.....	3-158
3.22.3.8.1	Check the bearing.....	3-158
3.22.3.8.2	Replace the bearing, if needed	3-159
3.22.3.9	Magnetic switch	3-159
3.22.3.9.1	Check continuity of the pull-in coil circuit.....	3-159
3.22.3.9.2	Check continuity of the hold-in coil circuit	3-159
3.22.3.10	Reassembly of starter.....	3-159
3.22.3.10.1	Fit the armature in the field frame	3-159
3.22.3.10.2	Install the brush holder.....	3-160

3.22.3.10.3	Insert the steel ball into the clutch shaft hole	3-160
3.22.3.10.4	Install the starter housing, clutch assembly and gear.....	3-160
3.22.3.10.5	Install the field frame, armature assembly and lead wire to the magnetic switch	3-161
3.22.3.11	Starter performance test.....	3-162
3.22.3.11.1	Pull-in test.....	3-162
3.22.3.11.2	Hold-in test	3-162
3.22.3.11.3	Check return of the clutch pinion gear	3-162
3.22.3.11.4	No-load performance test	3-162
3.22.4	Service Standard	3-163
3.23	Charging System.....	3-164
3.23.1	Preparation and Inspection	3-164
3.23.1.1	Inspect the drive belt	3-164
3.23.1.2	Visually check the alternator wiring and check for abnormal sounds	3-164
3.23.1.3	Check the discharge warning light circuit.....	3-164
3.23.1.4	Check the charging circuit at no load.....	3-165
3.23.1.5	Check the charging circuit at on load (Reference)	3-165
3.23.2	Alternator	3-166
3.23.3	Disassembly of Alternator	3-166
3.23.3.1	Remove the rear end cover	3-166
3.23.3.2	Remove the brush holder and IC regulator	3-167
3.23.3.3	Remove the rectifier holder.....	3-167
3.23.3.4	Remove the pulley	3-168
3.23.3.5	Remove the rectifier end frame	3-168
3.23.3.6	Remove the rotor from the drive end frame	3-169
3.23.4	Inspection and Repair of Alternator.....	3-169
3.23.4.1	Check continuity of the rotor circuit.....	3-169
3.23.4.2	Check the rotor grounding	3-169
3.23.4.3	Check the slip ring	3-169
3.23.4.4	Drive end frame (stator).....	3-169
3.23.4.4.1	Check continuity of the drive end frame circuit.....	3-169
3.23.4.4.2	Check grounding of the drive end frame	3-170
3.23.4.5	Brush.....	3-170
3.23.4.5.1	Check the exposed brush length.....	3-170
3.23.4.6	Rectifier (rectifier holder)	3-170
3.23.4.6.1	Check the positive rectifier	3-170
3.23.4.6.2	Check the negative rectifier	3-170
3.23.4.7	Bearing.....	3-170
3.23.4.7.1	Check the front bearing	3-170
3.23.4.7.2	Replace the front bearing when needed	3-171
3.23.4.7.3	Check the rear bearing	3-171
3.23.4.7.4	Replace the rear bearing when needed	3-171

3.23.5 Reassembly of Alternator	3-172
3.23.5.1 Locate the rectifier end frame on the pulley	3-172
3.23.5.2 Install the rotor to the rectifier end frame	3-172
3.23.5.3 Install the rectifier end frame	3-172
3.23.5.4 Install the pulley.....	3-173
3.23.5.5 Install the rectifier holder	3-173
3.23.5.6 Install the IC regulator and brush holder.....	3-174
3.23.5.7 Install the rear end cover	3-174
3.23.5.8 Check that the rotor rotates smoothly	3-174
3.23.6 Service Standards	3-175
3.24.1 Crankshaft Bearing Selecting TABLE (additional)	3-176
4. Troubleshooting	4-1
4.1 Does not Start or Difficult to Start	4-1
4.2 Unsmooth Running	4-2
4.3 Sudden Engine Stop	4-3
4.4 Poor Exhaust Gas Color	4-4
4.5 Insufficient Output	4-5
4.6 Ununiformity Output for Each Cylinder	4-6
4.7 Knocking	4-7
4.8 Trouble Related to Turbocharger	4-8
4.9 Other Malfunctions	4-9
5. Instrument Panel (Optional)	5-1
6. Electric Wiring Diagram	6-1
7. Tools	7-1
7.1 Special Tools	7-1
7.2 Special Tools (Local Supply)	7-3
7.3 Recommended Tools (Local Supply)	7-8
7.4 Equipment (Local Supply)	7-8
7.5 Service Special Materials (Local Supply)	7-10
7.6 Other Service Materials for Reference	7-11

1. For Safe Operation

1.1 Warning Symbols

- Most accidents are caused by negligence of basic safety rules and precautions. For accident prevention, it is important to avoid such causes before development to accidents. Please read this manual carefully before starting repair or maintenance to fully understand safety precautions and appropriate inspection and maintenance procedures. Attempting a repair or maintenance job without sufficient knowledge may cause an unexpected accident.
- It is impossible to cover every possible danger in repair or maintenance in the manual. Sufficient consideration for safety is required in addition to the matters marked **▲ CAUTION**. Especially for safety precautions in a repair or maintenance job not described in this manual, receive instructions from a knowledgeable leader.
- Warning Symbols used in this manual and their meanings are as follows:



DANGER - Indicates an imminently hazardous situation which, if not avoided, **WILL** result in death or serious injury.



WARNING - Indicates a potentially hazardous situation which, if not avoided, **COULD** result in death or serious injury.



CAUTION - Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

- Any matter marked [NOTICE] in this manual is especially important in serving. If not observed, the product performance and quality may not be guaranteed.

1.2 Precautions for Safe Servicing

(1) Service Shop (Place)

⚠ WARNING



● **Place allowing sufficient ventilation**

Jobs such as engine running, part welding and polishing the paint with sandpaper should be done in a well-ventilated place.

[Otherwise]

Very dangerous for human body due to the possibility of poisonous gas or dust inhalation.

⚠ CAUTION

● **Sufficiently wide and flat place**

The floor space of the service shop for inspection and maintenance shall be sufficiently wide and flat without any hole.

[Otherwise]

An accident such as a violent fall may be caused.

⚠ CAUTION

● **Clean, orderly arranged place**

No dust, mud, oil or parts shall be left on the floor surface.

[Otherwise]

An unexpected accident may be caused.

⚠ CAUTION



● **Bright, safety illuminated place**

The working place should be illuminated sufficiently and safely. For a job in a dark position involving difficulty in observation, use a portable safety lamp. The bulb shall be covered with a wire cage.

[Otherwise]

The bulb may be broken accidentally to cause ignition of leaking oil.


⚠ CAUTION



● **Place equipped with a fire extinguisher**


Keep a first aid kit and fire extinguisher close at hand in preparation for an emergency of fire.

(2) Working Wear


⚠ CAUTION	● Wears for safe operation
	Wear a helmet, working clothes, safety shoes and other safety protectors matching each job. Especially, wear well-fitting working clothes.
	[Otherwise]
	A serious accident such as trapping by a machine may arise.

(3) Tools to Be Used


⚠ WARNING	● Appropriate holding and lifting
	Never operate when the engine is supported with blocks or wooden pieces or only with a jack. To lift and hold the engine, always use a crane with a sufficient allowance in limit load or a rigid jack.
	[Otherwise]
	A serious accident may arise.

⚠ WARNING	● Use of appropriate tools
	Use tools matching the jobs to be done. Use a correctly sized tool for loosening or tightening a machine part.
	[Otherwise]
	A serious injury or engine damage may arise.

(4) Use of Genuine parts, Oil and Grease

⚠ CAUTION	● Always use genuine product
	[Otherwise] Shortening of engine life or an unexpected accident may arise.

(5) Bolt and Nut Tightening Torques

⚠ WARNING	● Always tighten to the specified torque if designated in the manual
	[Otherwise] Loosening or falling may cause parts damage or an injury.

(6) Handling Of Product

▲ WARNING



● **Pay attention to hot portions**

Do not touch the engine during running or immediately after it is stopped.

[Otherwise]

Scalding may be caused by a high temperature.

▲ WARNING



● **Pay attention to the rotating part**

Never bring clothes or a tool close to the rotating part during engine running.

[Otherwise]

Injury may be caused by entraping.

▲ WARNING



● **Harness short-circuit**

Disconnect the battery negative (-) terminal before starting the service job.

[Otherwise]

Shorting of a harness may occur to start a fire.

▲ WARNING



● **Battery charging**

Since flammable gas is generated during battery charging, keep any fire source away.

[Otherwise]

Explosion may arise.

▲ WARNING



● **Battery electrolyte**

Since the electrolyte is diluted sulfuric acid, do not let it be splashed onto clothes or skin.

[Otherwise]

The clothes or skin may be burnt.

(7) Waste Disposal

⚠ CAUTION

Observe the following instructions with regard to waste disposal. Negligence of each instruction will cause environmental pollution.

- Waste fluids such as engine oil and cooling water shall be discharged into a container without spillage onto the ground.
- Do not let waste fluids be discharged into the sewerage, a river or the sea.
- Harmful wastes such as oil, fuel, coolants, solvents, filter elements and battery shall be disposed according to the relevant laws and regulations. Ask a qualified disposal company for example.

(8) Safety Label Check

⚠ CAUTION

- Pay attention to the product safety label.


A safety label (caution plate) is affixed on the product for calling special attention to safety.

If it is missing or illegible, always affix a new one.

1.3 Location for Product Safety Labels

To insure safe operation, product safety labels have been attached. Their location is shown in the diagram below. Keep the labels from becoming dirty or torn and replace them if they are lost or damaged. Also replace labels when parts are replaced, ordering them in the same way parts are ordered.

Product Safety Labels, Parts Code Numbers	
①	120324-07240
②	128296-07260
③	119773-07280
④	128296-07300
⑤	128296-07360



The above diagram shows an overhead view of the engine.

2. General

2.1 Specifications

Engine model		6LP-DTE	6LP-STE	6LP-DTZE (1)	6LP-STZE (1)		
Type	Vertical water-cooled 4-cycle diesel engine						
Number of cylinders – Bore × stroke	mm	6 – φ 94 × 100					
Displacement	ℓ	4.163					
Aspiration system	Turbocharger, intercooler						
Cont. rating output	kW{hp}/rpm (Output/Flywheel)	154 {210}/3600	188 {255}/3600	154 {210}/3600	188 {255}/3600		
Max. output	kW{hp}/rpm (Output/Flywheel)	184 {250}/3800	221 {300}/3800	184 {250}/3800	221 {300}/3800		
High idling	(rpm)	4200 ± 25					
Low idling	(rpm)	750 ± 25					
Combustion system	Direct injection						
Starting system	Electric starting						
Cooling system	Constant high temperature fresh water cooling (2 cooling systems: seawater & fresh water)						
Lubrication system	Forced lubrication system with gear pump						
Direction of rotation	(Crankshaft)	Clockwise when viewed from stern side					
Fuel injection pump	BOSCH-distributor type Model VE6 (DENSO Co.)						
Fuel injection nozzle	Dual spring type Pinhole injection nozzle 6LP-DTE/-DTZE/-DTZE1: DLLA141P678 (5-0.30 × 140°) 6LP-STE/-STZE/-STZE1: DLLA141P677 (5-0.32 × 141°)						
Turbocharger	RHE62W(IHI)Water cooling and forced lubrication system with waste gate						
Elec. devices	Starter	DC12V - 2.5kW					
	Alternator	DC12V - 80A					
Lube oil capacity	ℓ	10.0	10.5	10.0	10.5		
Cooling water capacity	ℓ	13.5					
	Subtank	1.6					
Dimensions (L × W × H)	mm	1065 × 671 × 729	1065 × 671 × 729	1145 × 699 × 729	1145 × 699 × 729		
Dry weight (engine only)	kg (N)	380 (3724)	408 (3998)	400 (3920)	428 (4194)		
On-board marine drive	Maker	[Note] Marine drive with SAE#3 structure can be used. Example : HURTH (Italy) HSW630A1 Marine gear			MERCUISER (USA)		
	Type				BRAVO-1	BRAVO-2	BRAVO-3
	Speed ratio Ahead/Astern				1.36	1.50	1.36
		1.50	1.65	1.50	1.65		
		1.50	1.81	1.65	1.81		
Engine installation style	Rubber vibro-isolating mount						
Recommended battery capacity	12V-80Ah(5HR) or greater						
Recommended engine room ventilator	20m ³ / min. or greater						

※ -DTZE1/-STZE1 : less power steering oil pump (Engine name designated by the engine manufacturer)
(Shown as 6LP-DTZE/STZE in the name plate)

2. General

Engine model		6LPA-DTP	6LPA-DTZP
Type		Vertical water-cooled 4-cycle diesel engine	
Number of cylinders – Bore × stroke	mm	6– φ 94 × 100	
Displacement	ℓ	4.164	
Fuel stop power at crankshaft kW{hp}/rpm		*191 {260} / 3800 **182 {248} / 3800	
Cont. power at crankshaft kW{hp}/rpm		154 {210} / 3600	
High idling	(rpm)	4200 ± 25	
Low idling	(rpm)	750 ± 25	
Combustion system		Direct injection	
Starting system		Electric starting (12V-2.5kW)	
Charging system		Regulator built in Alternator DC12V-80A	
Cooling system		Constant high temperature fresh water cooling (2 systems: sea & fresh water)	
Lubrication system		Forced lubrication system with trochoidal gear pump	
Direction of rotation (Crankshaft)		Counter-clockwise (Viewed from flywheel side)	
Lube oil capacity	All	ℓ 10.0	
	Oil pan	ℓ 8.4	
Cooling water capacity		ℓ 13.5 (Engine), 1.6 (Sub-tank)	
Turbocharger	Model	RHE62W (IHI made)	
	Type	Water cooled turbine housing	
Dimensions (L × W × H) (gear less) mm		1065 × 671 × 729	1145 × 752 × 799
Dry mass (gear less) kg		380	400
Recommended battery capacity		12V × 120Ah	
Recommended type of remote control handle		Single lever type only	
Engine installation style		On the flexible engine mount	

- (Note) 1. Rating condition: ISO 3046-1, 8665 2. 1hp=0.7355 kW
3. Fuel condition: Density at 15°C=0.860, Fuel oil temperature *: 25°C at the fuel injection pump inlet
**: ISO 8665 (Fuel oil temp. 40°C at the fuel injection pump inlet)

● Marine gear (Option)

Model	HURTH HSW630A1	MERCUISER		
		Bravo X-1	Bravo X-2	Bravo X-3
Type	8° down Hydraulic	Stern drive		
Available engine	6LPA-DTP	6LPA-DTZP		
Reduction ratio HSW630A: Ahead/Astem Bravo X-1, 2, 3: Both Ahead and Astem	1.22/1.21	1.36	1.50	1.36
	1.56/1.58	1.50	1.65	1.50
	2.04/2.10	1.65	1.81	1.65
	2.52/2.53		2.00	1.81
			2.20	2.00
For further detail, refer to the maker's manual				

Engine model		6LPA-STP	6LPA-STZP
Type		Vertical water-cooled 4-cycle diesel engine	
Number of cylinders – Bore × stroke mm		6– φ 94 × 100	
Displacement ℓ		4.164	
Fuel stop power at crankshaft kW{hp}/rpm		*232 {315} / 3800 **222 {301} / 3800	
Cont. power at crankshaft kW{hp}/rpm		188 {255} / 3600	
High idling (rpm)		4200 ± 25	
Low idling (rpm)		750 ± 25	
Combustion system		Direct injection	
Starting system		Electric starting (12V-2.5kW)	
Charging system		Regulator built in Alternator DC12V-80A	
Cooling system		Constant high temperature fresh water cooling (2 systems: sea & fresh water)	
Lubrication system		Forced lubrication system with trochoidal gear pump	
Direction of rotation (Crankshaft)		Counter-clockwise (Viewed from flywheel side)	
Lube oil capacity	All ℓ	10.5	
	Oil pan ℓ	8.4	
Cooling water capacity ℓ		13.5 (Engine), 1.6 (Sub-tank)	
Turbocharger	Model	RHE62W (IHI made)	
	Type	Water cooled turbine housing	
Dimensions (L × W × H) (gear less) mm		1065 × 671 × 729	1145 × 752 × 799
Dry mass (gear less) kg		408	428
Recommended battery capacity		12V × 120Ah	
Recommended type of remote control handle		Single lever type only	
Engine installation style		On the flexible engine mount	



(Note) 1. Rating condition: ISO 3046-1, 8665 2. 1hp=0.7355 kW
3. Fuel condition: Density at 15°C=0.860, Fuel oil temperature *: 25°C at the fuel injection pump inlet
**: ISO 8665 (Fuel oil temp. 40°C at the fuel injection pump inlet)

● Marine gear (Option)

Model	HURTH HSW630A1	MERCUISER		
		Bravo X-1	Bravo X-2	Bravo X-3
Type	8° down Hydraulic	Stern drive		
Available engine	6LPA-STP	6LPA-STZP		
Reduction ratio HSW630A1: Ahead/Astem Bravo X-1, 2, 3: Both Ahead and Astern	1.22/1.21	1.36	1.50	1.36
	1.56/1.58	1.50	1.65	1.50
	2.04/2.10		1.81	1.65
	2.52/2.53		2.00	1.81
For further detail, refer to the maker's manual				

2.2 External Views


- 6LP-DTE/-STE, 6LPA-DTP/-STP




Note: 6LP-DTE has almost same external shape as 6LP-STE but it does not include a lube oil cooler(2).
(※ mark) The above illustrations show the 6LP-STE attaching the HURTH marine gear.
The external shape of the 6LPA-DTP/-STP is identical with that of 6LP-DTE/-STE.

• 6LP-DTZE/-DTZE1/-STZE/-STZE1, 6LPA-DTZP/STZP

F.I. Pump Side



Exhaust Side



Note: The 6LP-STZE engine (stern driving device : BRAVO, MERCURISER) is used as the example for the above drawings.

※ (A) (indicated) oil cooler (2) is for the 6LP-STZE/-STZE1, 6LPA-STZP engines.

6LP-DTZE/-DTZE1, 6LPA-DTZP engines do not have one.

※ (B) (indicated) power steering oil pump, oil tank, oil cooler are parts for 6LP-DTZE/-STZE, 6LPA-DTZP/-STZP engines.


6LP-DTZE1/-STZE1 engines do not have these.

6LP-DTZE and 6LP-STZE are the same outline as 6LPA-DTZP and 6LPA-STZP respectively.

6LP-DTZE1/-STZE1 are the name designated by the engine manufacturer to identify the less power steering engine. (6LP-DTZE, 6LP-STZE in the nameplate)

2.3 Piping Diagram


• 6LP-DTE/-STE, 6LPA-DTP/-STP



6LP-STE/6LPA-STP
 * Lube Oil Cooler (Sea Water Cooling)
 * is not attached on the Model 6LP-DTE/6LPA-DTP

MARKS	NAME OF PARTS
—▶—	Fuel Oil Piping
- - -▶-	Lube Oil Piping
.....▶.....	Cooling Fresh Water Piping
- - -▶-	Cooling Sea Water Piping
.....X.....	Drilled Flow Line (Hole)
→←	Inserted Pipe Coupling
┴	Eye type Pipe Coupling
	Screwed type Pipe Coupling
	Flanged type Pipe Coupling

• 6LP-DTZE/-DTZE1/-STZE/-STZE1, 6LPA-DTZE/-STZE




* is not attached on the Model 6LP-DTZE, 6LPA-DTZE


MARKS	MAME OF PARTS
—▶—	Fuel Oil Piping
- - -▶-	Lube Oil Piping
.....▶.....	Cooling Fresh Water Piping
- - -▶-	Cooling Sea Water Piping
- - -▶-	Power Steering Oil Piping
.....✕.....	Drilled Flow Line (Hole)
▶—←	Inserted Pipe Coupling
┌—┐	Eye type Pipe Coupling
┌—┐	Screwed type Pipe Coupling
┌—┐	Flanged type Pipe Coupling

2.4 Performance Curves

- 6LP-DT(Z)E/-DTZE1 (Max. output : 184 kW/3800 rpm)




- 6LP-ST(Z)E/-STZE1 (Max. output : 221 kW/3800 rpm)




2. General

- 6LPA-DTP (Fuel stop power : 191 kW/3800 rpm)




• 6LPA-DTZP (Fuel stop power : 191 kW/3800 rpm)






2. General

- 6LPA-STP (Fuel stop power : 232 kW/3800 rpm)




• 6LPA-STZP (Fuel stop power : 232 kW/3800 rpm)



2.5 Front Power Take-Off (PTO) Output

- Front PTO diagram




[Method for Front PTO]

- (1) Use type A (Belt drive with no outside bearing). Do not use other types of PTO.
- (2) Do not employ the up-pull drive. Use the side pull belt drive.
- (3) Use a single V-drive, type A.
- (4) The PTO pulley should be aluminum. The outside diameter should be max. $\phi 170$ mm and the overhang within 25 mm.
- (5) Install the pulley to the exterior of the viscous damper and tighten the pulley and damper with the damper fixing bolts (M8 \times 6 pcs.) and the washers.
(Tightening torque: 3.8 ± 0.2 kg-m (37.27 ± 1.96 N·m))


Please note that the crankshaft may break if the front PTO output exceeds the allowable output.

The pulley thickness should be 10 mm.



V-pulley overhang

A-Type
 V-Belt style : A
 Material : Aluminum
 Equivalent inertia weight
 : 0.065 kg. cm. sec²
 (0.63 N. cm. sec²)



V-pulley drawing

2.6 Fuel Oil

(1) Selection of Fuel Oil

Use the following diesel fuels and select fuels of a higher quality for best engine performance.

[Diesel fuel standard for various countries]

- ISO 8217 DMA
- JIS K2204 Grade No.2, No.3 or special-No.3
- BS 2869 Part-1 class-A1 or A2

At low temperatures, fuel oil becomes difficult to ignite and will not flow easily, making starting difficult. Select fuel oil of a cetane number of 45 or greater to insure ignitability, and use the outside temperature as a guide for selecting the proper grade to insure fluidity.


[NOTICE]

When other than the specified fuel oil is used, the engine will not perform to full capacity and parts may be damaged.

Sample for recommended fuel oil	
Standard for fuel oil	JIS K2204
Pour point (Temperature)	
-7.5°C or greater	Grade No.2
-20°C or greater	Grade No.3
-30°C or greater	Grade No.3-Sp.
Cetane fuel number	45 or greater

(2) Handling of Fuel Oil


- Keep the fuel oil in a clean container. Store the container in a place away from rain and dirt as water and dust mixed in with the fuel cause engine failure.
- Keep the fuel container stationary for several hours to allow any dirt or water to settle to the bottom. Use a pump to extract the clear, filtered fuel from the top of the container for use.



(3) Fuel Piping

Install the fuel pipe from the fuel tank to the fuel pump in accordance with the diagram to the right. Be sure to attach a drain cock to the fuel tank to enable dirt and water which have settled at the bottom of the tank to be drained off.

The oil/water separator (optional) is placed at the center section of the line.



2.7 Lube Oil

(1) Selection of Engine Lube Oil

Use the following lube oil:

- *API Classification CD
(Standards of America Petroleum Institute)
- *SAE Viscosity 15W40
(Standards of Society of Automotive Engineering)

[NOTICE]

Using other than the specified lube oil will lead to seizure of parts inside the engine and gear device, abnormal wear, and shorten engine life. It will also affect the starting ability and power output.

(2) Selection of Marine Drive Oil

Refer to the operation manual for the marine drive unit for the selection of the proper lube oil.

- For **MERCURISER's** stern-driven (**BRAVO**) use the following lube oil.

6LP-DTZE (1)

6LP-STZE (1)

6LPA-DTZP

6LPA-STZP

System Oil	Specified lube oil
Drive oil	Quicksilver High Performance Gear Lube
Power steering oil ※	Quicksilver Power Trim and Steering Fluid or Dexlone- II
Power trim oil	Quicksilver Power Trim and Steering Fluid or SAE 10W-30 or 10W-40 engine oil

※ for 6LP-DTZE/-STZE, 6LPA-DTZP/-STZP

(3) Handling the Lube Oil

- When handling and storing lube oil, be careful not to allow dust and water to enter the lube oil. Clean around the filter post before refilling.
- Do not mix lube oils of different types or brands. Mixing may reduce the lubricating performance. Different oils are used for the engine and the marine drive unit. Be careful to use the correct oil for each one and store in separate clearly labeled containers.


2.8 Cooling Water

- Always use soft water (tap water) for the fresh water. Never use dirty water or hard water. Impurities in the cooling water cause scale and rust to build up in the cooling system reducing cooling efficiency and causing the engine to overheat.
- During the cold season, add antifreeze to the cooling water to prevent freezing. Failure to add antifreeze will result in damage to various parts in the cooling water system.
- Consult your Yanmar dealer or distributor on the use of antifreeze, anti-rust, and detergents.

[NOTICE]

- **Refer to the instructions accompanying the antifreeze for the proper mixing ratio. Select the ratio for the lowest temperature of the cold season. If the mixture is too thick, the cooling efficiency will be reduced.**
- **Do not mix different brands of antifreeze or anti-rust. Mixing reduces cooling efficiency and leads to parts damage.**
- **When the amount of cooling water is too low, refill with fresh water only.**

2.9 Location of Senders and Warning Switches



3. Engine Overhaul


3.1 Cylinder Head

3.1.1 Components

[NOTICE]

- *Cylinder numbers No.1, No.2 and on are allocated starting from the gear case side.*
- *Avoid placing the engine body directly on the floor. Otherwise, the oil pan may be bent.*
- *6LP-DTE series or 6LP-DTE series only includes 6LPA-DTP series.*
- *6LP-STE series or 6LP-STE series only includes 6LPA-STP series in this descriptions.*

(1) 6LP-DTE series



**Thank you very much
for your reading.**

Please Click Here

**Then Get More
Information.**