

INSTRUCTION



Assemble 6X branches, wire cables, insulate cables.
Make sure below 3X screws are tight for your safety



Recommend assemble on the floor on a timber slat first.

