

If equipped, the amplifier is under the driver seat. On vehicles with amplifier, the speaker wires are white/blue - black/yellow at the amplifier, white 18 pin plug, pins 8 and 18. The tweeter wires are white/blue - black/yellow at the amplifier, white 14 pin plug, pins 6 and 14.

Right Front Speaker (+/-)	white/red - black/red	+, -	radio, white 20 pin plug, pins 6 and 16
If equipped, the amplifier is under the driver seat. On vehicles with amplifier, the speaker wires are white/red - black/red at the amplifier, white 18 pin plug, pins 7 and 17. The tweeter wires are white/red - black/red at the amplifier, white 14 pin plug, pins 5 and 13.			
Left Rear Speaker (+/-)	yellow/blue - gray/blue	+, -	radio, white 20 pin plug, pins 7 and 17
If equipped, the amplifier is under the driver seat. On vehicles with amplifier, the speaker wires are yellow/blue - gray/blue at the amplifier, white 14 pin plug, pins 1 and 7.			
Right Rear Speaker (+/-)	yellow/red - gray/red	+, -	radio, white 20 pin plug, pins 5 and 15
If equipped, the amplifier is under the driver seat. On vehicles with amplifier, the speaker wires are yellow/red - gray/red at the amplifier, white 14 pin plug, pins 2 and 8.			
Center Channel (+/-)	N/A		
Subwoofer (+/-)	green - yellow (1); blue - white (2)	+, -	amplifier, white 18 pin plug, pins 1 and 9; 2 and 10
If equipped, the amplifier is under the driver seat.			
Aux. Audio Input Left (+/-)	blu - blk (Lancer), blu/wht - blk/wht (Lancer Evo)	+, -	radio, white 18 pin plug, pins 13 and 14
Aux. Audio Input Right (+/-)	pink - black (Lancer), pur - blk/wht (Lancer Evo)	+, -	radio, white 18 pin plug, pins 4 and 14
RSE Video (+/-)	N/A		
RSE Audio Left (+/-)	N/A		
RSE Audio Right (+/-)	N/A		
Satellite Radio 12 Volts	red/white or red	+	Satellite Radio Tuner, white 14 pin plug, pin 1
If equipped, the Satellite Radio Tuner is behind the glove box.			
Satellite Radio Ground	black	-	Satellite Radio Tuner, white 14 pin plug, pin 8
Satellite Radio Ignition	(CAN bus)		
Satellite Radio Antenna	(coaxial cable)		
Satellite Audio Left (+/-)	yellow - blue or black	+, -	Satellite Radio Tuner, wht 14 pin plug, pins 6, 7
Satellite Audio Right (+/-)	brown - blue or black	+, -	Satellite Radio Tuner, wht 14 pin plug, pins 14, 7

Item	Size	Depth	Location
Headunit	irregular		center of dash
Left Front Speaker	6.5		left front door
Left Front Tweeter	1.25		left front door
Right Front Speaker	6.5		right front door
Right Front Tweeter	1.25		right front door
Left Rear Speaker	6.5		left rear door
Left Rear Tweeter	N/A		
Right Rear Speaker	6.5		right rear door
Right Rear Tweeter	N/A		
Center Channel	N/A		
Subwoofer	10		left side of trunk
Left Front Headrest			
Right Front Headrest			
Left Rear Headrest			
Right Rear Headrest			
Satellite Radio Tuner			behind glove box